

SH-09 Lightweight Headset



Features:

- Flexible Boom Arm
- High-Quality Easy-Maintenance Headband
- Great Acoustic Performance
- Included Sweat Drip Ring
- Available in Black or Beige

The SH-09 is a "ruggedized" active headset for two-way radio communications for industrial, police, community service and warehouse applications.

An adjustable boom mic permits precise placement near the lips and stays in place during physical activity.

Fitted with a high quality microphone, it allows the user to communicate even in high noise environments and still transmits an intelligible message across to the recipient.

The low profile headband (behind the head) fits under most helmets, allowing the user to enjoy head protection while wearing a communication headset.

The loudspeaker is capable of producing very high and clear output and the earpiece is ergonomically designed to provide a very good and comfortable fit over the ear, preventing wearer fatigue.

Specifications:

Microphone

Generating Element:	Electret Condenser
Polar Pattern:	Choice of Noise-Canceling or Cardioid or Super-Cardioid or Omni
Current Drain	Less than 250µA

Gooseneck Diameter: 4mm

Loudspeaker

Frequency Range:	100Hz to 2.5kHz
Output:	121dB @1mW 1kHz w/IEC 711 coupler
Impedance:	32 ohms

Others

Water Resistance:	Splash Proof (optional – 1 meter immersion proof)
Cable:	TPE Black, Ø 3.6mm, 1.5m length
Termination:	Available with most standard terminations or comes unterminated, Custom terminations are available
Accessories:	Standard - Windscreen, ear cushion Optional - cable clips

* SH-09 is available in both right/left speaker versions