

SH-10 RUGGED HEADSET



The SH-10 is a rugged headset designed for two-way radio communications for industrial, police, community service and is also perfect for voice recognition devices in warehouse applications.

An adjustable boom mic permits precise placement near the lips and stays in place during physical activity.

Fitted with a high quality microphone, it allows the user to communicate even in high noise environments and still transmits an intelligible message across to the recipient or to a voice input device.

The low profile headband (behind the head) fits under most helmets, allowing the user to enjoy head protection while wearing a communication headset.

The adjustable headband is also easily removed and replaced when necessary.

Should the cable need to be replaced, a service technician can easily remove and replace the existing cable assembly.

The loudspeaker is capable of producing very high and clear output and the earpiece is ergonomically designed to provide a very good and comfortable fit over the ear, preventing wearer fatigue.

Features:

- Rugged and Robust design
- Replaceable adjustable headband
- Cable can be easily replaced
- Superb Microphone Acoustic Performance

SH-10 Specifications :

Microphone

Generating Element	Electret
Polar Pattern	Noise-Canceling (Cardioid, Super-Cardioid or Omni available on request)
Sensitivity	-42dB re 1V/Pa (typical)
Frequency Response	300Hz to 8kHz
Operating Voltage	2Vdc to 12Vdc

Loudspeaker

Frequency Response	300Hz to 6000Hz
Impedance	32ohms
Audio Output	121dB @1mW 1kHz w/IEC 711 coupler

Others

Water Resistance:	Splash Proof (optional – 1 meter immersion proof)
Cable:	TPE Black, Ø 3.6mm, 1.5m length
Termination:	Available with most standard terminations or comes un-terminated
Accessories:	Standard - Windscreen, ear cushion, adjustable headband Optional - cable clips

